

3. Safety instructions, Maintenance instructions, Warnings and Notes

Safety Instructions for Repairs

1. Safety regulations require that during a repair:
 - the set should be connected to the mains via an isolating transformer
 - safety components, indicated by the symbol  should be replaced by components identical to the original ones
 - when replacing the CRT, safety goggles must be worn.
2. Safety regulations require also that after a repair:
 - the set should be returned in its original condition
 - the cabinet should be checked for defects to avoid touching, by the customer, of inner parts
 - the insulation of the mains lead should be checked for external damage
 - the mains lead strain relief should be checked on its function
 - the cableform and EHT cable are routed correctly and fixed with the mounted cable clamps in order to avoid touching of the CRT, hot components or heat sinks
 - the electrical resistance between mains plug and the secondary side is checked. This check can be done as follows:
 - unplug the mains cord and connect a wire between the two pins of the mains plug
 - switch on the TV with the main switch
 - measure the resistance value between the pins of the mains plug and the metal shielding of the tuner or the aerial connection on the set. The reading should be between $4.5\text{ M}\Omega$ and $12\text{ M}\Omega$.
 - switch off the TV and remove the wire between the two pins of the mains plug
 - thermally loaded solder joints should be resoldered. This includes components like LOT, the line output transistor, fly-back capacitor.

Maintenance Instructions

It is recommended to have a maintenance inspection carried out periodically by a qualified service employee. The interval depends on the usage conditions.

- When the set is used in a living room the recommended interval is 3 to 5 years. When the set is used in the kitchen or garage this interval is 1 year.
- During the maintenance inspection the above mentioned "safety instructions for repair" should be carried out. The power supply and deflection circuitry on the chassis, the CRT panel and the neck of the CRT should be cleaned.




Fig. 3.1

Warnings

1. In order to prevent damage to IC's and transistors any flash-over of the EHT should be avoided. To prevent damage to the picture tube the method, indicated in Fig. 3.1, has to be applied to discharge the picture tube. Make use of an EHT probe and a universal meter (position DC-V). Discharge until the reading of the meter is 0V (after approx 30s).
 2. 
- All IC's and many other semi-conductors are sensitive to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically. When repairing, make sure that you are connected with the same potential as the mass of the set via a wrist wrap with resistance. Keep components and tools on the same potential.
3. Proceed with care when testing the EHT section and the picture tube.
 4. Never replace any modules or any other parts while the set is switched on.
 5. Use plastic instead of metal alignment tools. This will prevent any short circuits and the danger of a circuit becoming unstable.
 6. Upon a repair of a transistor or an IC assembly (e.g. a transistor or IC with heatsink and spring) remounting should be carried out in the following order:
 1. Mount transistor or IC on heatsink with spring.
 2. Resolder the joints.

Notes

1. Do not use heatsinks as earth reference.
2. The direct voltages and waveforms should be measured relative to the nearest earthing point on the printed circuit board.
3. The direct voltages and waveforms are measured in the Service Default Mode (see chapter 9). Use a colour bar pattern of a pattern generator (e.g PM5518)
4. The DC voltages and oscilloscopes are where necessary measured with  and without  aerial signal. Voltages and oscilloscopes in the power supply section have been measured for both normal operation (①) and in the stand-by mode (②). As an input signal a colour bar pattern has been used.
5. The picture tube PWB has printed spark gaps. each spark gap is connected between an electrode of the picture tube and the Aguadag coating.

4. Mechanical instructions

For the main carrier two service positions are possible:

A: For faultfinding on the component side of the main carrier

B: For (de)soldering activities on the copper side of the main carrier

Position A can be reached by first removing the mains cord from its fixation, then loosen the carrier lips (1) and then pulling the carrier panel (2) for approximately 10 cm.

Position B can be reached from position A after disconnecting the degaussing cable. Put the carrier on the line transformer side.

To put the radio or system module on the main-carrier, remove PCB out of the bracket and put it in the position displayed in Fig. B.




Fig. 4.1





Fig. 4.2

5. Overview oscilloscopes / Übersicht Oszillogramme / Vue d'ensemble des oscillosogrammes


Chassis AA5H 4



OSC_AA5_H1aa.AI
040396

Survey of testpoints / Übersicht über die Teststellen / Presentation des points à tester


Main carrier (Component side)



CL 66532007_011.AI
300196


Fig. 5.1

Mini neck CRT panel (Back view)



CL 66532013_012.AI
010396


Narrow neck CRT panel (Back view)




CL 66532007_012.AI
010396

Fig. 5.2


Fig. 5.3




13 Power supply / Speisung / Alimentation (Part 2)




Power supply / Speisung / Alimentation







Deflection / Ablenkung / Déflexion (Part 2)


Deflection / Ablenkung / Déflexion








Controls / Bedienung / Commandes


Chassis AA5H 16













19 Teletext / Videotext / Télétexthe




T2 5V DC



T3 4V9 DC




T8





T9




Fast text panel






14-15-17-21" Mini neck CRT panel





Wave forms [B1] / [B2]




→ = 0V
OSC_B1.A1
190396

21" Narrow neck CRT panel






20-21" Narrow neck CRT panel / Bildröhren Platte / Platine TRC



A	0002	E10
B	0002	D10
C	0002	C10
D	0002	B10
E	0002	A10
F	0002	H5
G	0002	C5
H	0002	A1
I	0002	K1
J	0002	C1
K	0002	L8



I	0002	J
J	0002	J
K	0002	K




Extra Power supply / Zusätzliche Stromversorgung /

Chassis AA5H 23


Alimentation Additionelle




External Power Supply / Externe Stromversorgung



Alimentation Externe




Clock panel / Uhr-Platte / Platine d'horloge



Chassis AA5H 24

Radio Module / Radiomodul / Module de radio



Smart loader / Smart Lader / Chargeur à mémoire

