

T.sonic™ 840 Firmware Update Procedure


(Please make sure you backup all the data before continuing the firmware update procedure.)

Notice:


- a. Before beginning the procedure, please disconnect your T.sonic™ 840 from your computer.
- b. This firmware update program only supports Windows 2000, Windows XP, and Windows Vista. (Please log in with Administrator privileges)
- c. This procedure WILL delete all the files in your T.sonic™ 840.
- d. Please DO NOT connect your T.sonic™ 840 to any types of USB hubs, including USB ports on your monitor or keyboard.

Procedure:

1. Before beginning the procedure, please disconnect your T.sonic™ 840 from your computer. **Press and hold the “Reset” button on T.sonic™ 840 for 2 seconds.**
2. **Press and hold the “Volume Down” button (until step 4) and connect T.sonic™ 840 to an available USB port on a computer.**
3. Extract the download file and then double click on the executable file to execute the “T.sonic 840: Firmware Upgrade” software program.



4. Click on the “Search Device” button to continue. A “Current Version: 00.00.00” message will be displayed in the window indicating that the T.sonic™ 840 has been successfully found. You may release the “Volume Down” button now.



5. Click on the "OK" button to begin updating the firmware version of your T.sonic™ 840. This may take a few minutes. When the firmware update process completes, a "Firmware Upgrade Completed..." message will appear. Please click on the "OK" button to close the "T.sonic 840: Firmware Upgrade" program. Congratulations, your T.sonic™ 840 is now updated.

Reminder: Always disconnect the T.sonic™ 840 from a computer by selecting and following the instructions for the `Safely Remove Hardware` icon that can be found on the Windows Toolbar at the bottom of the computer screen.

