

11 Disassembly and Reassembly

This section of the service manual describes the disassembly and reassembly procedures for the LDO19WS TFT-LCD monitors.

⚠ WARNING: This monitor contains electrostatically sensitive devices. Use caution when handling these components.

11-1 Disassembly

- ⚠ Cautions:**
1. Disconnect the monitor from the power source before disassembly.
 2. Follow these directions carefully; never use metal instruments to pry apart the cabinet.




1. Place monitor face down on cushioned table. Remove 4 screws from the stand.





2. Remove 3 screws from the rear-cover. Lift up the rear-cover.



11 Disassembly and Reassembly




3. Remove 4 screws from the shield-cover.



4. Remove 2 screws from the side connector. Lift up the shield-cover.



5. Remove 9 screws from the boards. Remove 9 screws from the BRKT.



6. Lift up the Panel-BRKT.



11-2 Reassembly

-Reassembly procedures are in the reverse order of disassembly procedures.

Memo