


10 Operating Instructions and Installation

10-1 Front



1. SOURCE

Switches from PC Mode to Video mode. Changing the source is allowed only in external devices that are connected to the monitor at the time.

To switch Screen modes:

[PC] - [DVI] - [TV] - [Ext.] - [AV] - [S-Video] - [Component]

2. PIP (Available in PC/DVI/Component Mode)

In PC Mode, turns on Video or TV screens in PIP mode.

3. MENU

Use this button for open the on-screen menu and exits from the menu screen or closes screen adjustment menu.

4. ∨ CH ∧

Moves from one menu item to another vertically or adjusts selected menu values.

In TV mode, selects TV channels.

5. — VOL +

Moves from one menu item to another horizontally or adjusts selected menu values. Adjusts the audio volume.

6. [Enter] Enter button

Activates a highlighted menu item.

7. [Power] Power button

Use this button to turn the monitor on and off.

8. Power indicator

Power Indicator shows PowerSaver mode by green blinking.

9. Remote Control Sensor

Aim the remote control towards this spot on the monitor.

10. Speaker

You can hear sound by connecting the soundcard of your PC to the monitor.

10-2 Rear




1. POWER

Power terminal

Connect the power cord for your monitor to the POWER on the back of the monitor.

This product may be used with 100 ~ 240VAC (+/- 10%).



2.DVI/PC IN

1) DVI(HDCP)

: Connect the DVI cable to the DVI(HDCP) port on the back of your monitor.

2) RGB

: Connect the signal cable to the RGB port on the back of your monitor.

3) AUDIO

: PC sound terminal (input)




3. EXT(RGB)

External device terminal

EXT(RGB) is mainly used in Europe.

As for EXT(RGB) port of the monitor, it makes TV or Video signal input and output.



4. COMPONENT IN

1) R - AUDIO - L

: DVD/DTV sound input terminal (left/right)

2) PR, PB, Y

: DVD/DTV video input terminal(PR, PB, Y)



5. ANT IN

TV antenna terminal



6. AV connection terminal

- 1) : Headphone sound output terminal
- 2) S-VIDEO : External device (S-video) input terminal
- 3) VIDEO : External device (video) input terminal
- 4) R - AUDIO - L : External device sound input terminal




7. Kensington Lock

The Kensington lock is a device used to physically fix the system when using it in a public place.

(The locking device has to be purchased separately.)

For using a locking device, contact where you purchase it.

10-3 Remote Control



1. POWER
2. Number button
3. +100, -/--
4. - ∇ +
5. MUTE
6. TTX/MIX
7. MENU
8. ENTER
9. CH/P
10. SOURCE
11. INFO
12. EXIT
13. Up-Down Left-Right buttons
14. AUTO
15. P.MODE, M/B (MagicBright™)
16. P.SIZE
17. STILL
18. PIP
19. S.MODE
20. DUAL/MTS
21. PRE-CH
22. SOURCE
23. SIZE
24. POSITION
25. MAGIC-CH

1. POWER

Use this button to turn the monitor on and off.

2. Number button

Selects TV channels in the TV mode.
You may use this button in PIP mode as well.

3. +100


Press to select channels over 100.
For example, to select channel 121, press "+100", then press "2" and "1".
-/-- (One/Two-Digit channel selection)

Use to select a channel numbered ten or over.
Press this button, and the "--" symbol is displayed.
Enter the two-digit channel number.
This function is available only in Europe.

4. - +

Adjusts the audio volume.

5. MUTE

Pauses (mutes) the audio output temporarily.
Displays on the lower left corner of the screen.
The audio resumes if mute or -  + is pressed in the Mute mode.

6. TTX/MIX

TV channels provide written information services via teletext.
This function is available only in Europe.

7. MENU

Use this button to open the on-screen menu and exit from the menu screen or close screen adjustment menu.

8. ENTER

Activates a highlighted menu item.

9. CH/P

In TV mode, selects TV channels.

10. SOURCE

Switches from PC Mode to Video mode.
Changing the source is allowed only in external devices that are connected to the monitor at the time.

11. INFO

Current picture information is displayed on the upper left corner of the screen.

12. EXIT

Exits from the menu screen.

13. Up-Down Left-Right buttons

Moves from one menu item to another horizontally, vertically or adjusts selected menu values.

14. AUTO - Available in PC Mode Only

Adjusts the screen display automatically.

15. P.MODE, M/B (MagicBright®)

When you press this button, current mode is displayed on the lower center of the screen.

TV / AV / Ext. / S-Video /Component Mode :
P.MODE(Picture Mode)

The monitor has four automatic picture settings that are preset at the factory.
Then push button again to circle through available preconfigured modes.
(Dynamic ;æ Standard ;æ Movie ;æ Custom)

PC / DVI Mode : M/B (MagicBright®)

MagicBright® is a new feature providing the optimum viewing environment depending on the contents of the image you are watching.
Then push button again to circle through available preconfigured modes.
(Entertain;æ Internet ;æ Text ;æ Custom)

16. P.SIZE - Not available in PC/DVI Mode

Press to change the screen size.
(Auto Wide ;æ Wide ;æ Panorama ;æ Zoom1 ;æ Zoom2 ;æ 4:3)
Panorama, Zoom1, Zoom2 are not available in 1080i(or over 720p) of DTV.

17. STILL - Not available in PC/DVI/Component Mode

Press the button once to freeze the screen. Press it again to unfreeze.

18. PIP - Available in PC/DVI/Component Mode

Push the PIP button to turn PIP screen On/Off.

19. S.MODE (Sound Mode)

When you press this button, current mode is displayed on the lower center of the screen.
The monitor has a built-in high fidelity stereo amplifier.
Then push button again to circle through available preconfigured modes.
(Standard ;æ Music ;æ Movie ;æ Speech ;æ Custom)

20. DUAL / MTS

DUAL : STEREO/MONO, DUAL I / DUAL II and MONO/NICAM MONO/NICAM STEREO can be operated depending on broadcasting type by using DUAL button on the remote control while watching TV.

MTS : You can select the MTS (Multichannel Television Stereo) mode.

- Mono, Stereo, SAP (Separate Audio Program)
Set 'MTS' to ON to choose Mono, Stereo or SAP.

21. PRE-CH

This button is used to return to the immediately previous channel.

22. SOURCE - Available in PIP Mode

Selects the Video source.

23. SIZE - Available in PIP Mode

You can switch the PIP picture size.

24. POSITION - Available in PIP Mode

Changes the Position of the PIP window.

25. MAGIC-CH

MagicChannel enables you to watch only certain channels.

This function is available only in Korea.

Memo