

This Firmware Update is only supported in Windows® 2000 and XP

Please make sure you backup all the data before continuing firmware update procedure.

Instructions for Updating the Firmware Version of your Transcend T.sonic™ 610 MP3 Player in Windows® Me, 2000 and XP.

1. You must log in with Administrative privileges to install “T.sonic 610 Driver and Firmware”.
2. Open the “T.sonic 610 Firmware V3.3” folder and double click the “SETUP.EXE” file to install the Firmware Update program to your computer.
3. Before beginning the procedure, please disconnect your T.sonic™ 610 from your computer. Press the “Reset” button on T.sonic™ 610 for 2 seconds.




3. Click the “Start” button located on the task bar and select **Programs >> Transcend T.sonic 610 v3.3 >> Transcend T.sonic 610 Firmware Update v3.3.**



4. Select your language.



5. Confirm that you wish to go through with the Firmware Update process. (Please make sure you backup all the data before continuing firmware update procedure.)




6. Press and hold the "Play" button and connect T.sonic™ 610 to an available USB port on the computer until the "Transcend T.sonic 610 Firmware Update" window appears.



7. The "Found New Hardware Wizard" window will appear if it is the first time you use the T.sonic™ 610 updater in your computer. Select the "Yes, now and every time I connect a device" option and click on the "Next" button to continue.




8. The "Found New Hardware Wizard" will guide you through the Firmware Update process.



9. It may take a few minutes for the system to search **T.sonic™ 610**. If there is no response within 3 minutes, please press the "Reset" button again. The system will begin searching **T.sonic™ 610** again. The Firmware Update Program will detect **T.sonic™ 610** automatically.

10. Select the "Format Data Area" option then click the "Start" button to begin to update latest firmware version into your **T.sonic™ 610**. This may take a few minutes.



13. After the firmware update process has completed, a “**Completed**” message will appear. Click the “**Close**” button to exit the “**T.sonic 610: Firmware Upgrade v3.3**” software program. Congratulations, the latest firmware has been now updated into your **T.sonic™ 610**.

