

11 Disassembly and Reassembly

This section of the service manual describes the disassembly and reassembly procedures for the LE23T51B/LE27T51B/LE32T51B TFT-LCD monitors.

⚠ WARNING: This monitor contains electrostatically sensitive devices. Use caution when handling these components.

(ONLY LE32T51B) Check the connector of POWER BOARD which are CNM 802, 803.
IF Panel MARK is A(AUO), The wire which is from PANEL INVERTER Must be connected into CNM 803.


IF Panel MARK is S(Sec), The wire which is from PANEL INVERTER Must be connected into CNM 802.

11-1 Disassembly

⚠ Cautions: 1. Disconnect the monitor from the power source before disassembly.



1. Place LCD-TV face down on cushioned table.
 Remove 14 screws from the rear-cover and Remove stand.




2. Remove 2 screws from the cover-jack.
 Lift up the rear-cover.



11 Disassembly and Reassembly



3. Disconnect cables and remove 6 screws from the power board.





4. Remove 4 screws from the main board.
Lift up the power board.



5. Lift up the main board and remove 10 screws from the BRKT.



6. Remove 4 screws and Lift up the Lcd panel.



7. Remove 4 screws

11-2 Reassembly

Reassembly procedures are in the reverse order of disassembly procedures.

Memo