



10 Operating Instructions and Installation

10-1 Front



- The product color and shape may vary depending on the model.


1. SOURCE

Displays a menu of all of the available input sources (TV, Ext.1, Ext.2, AV, S-Video, Component, PC, DVI). In the on-screen menu, use this button as you use the ENTER  button on the remote control.



2. MENU

Press to see an on-screen menu of your TV's features.

3. + -

Press to decrease or increase the volume. In the on-screen menu, use the +  - buttons as you use the ◀ and ▶ buttons on the remote control.

4. C/P. ^

Press to change channels. In the on-screen menu, use the  C/P.  ^ buttons as you use the ▼ and ▲ buttons on the remote control.

5. (HEADPHONE JACK)

Connect a set of external headphones to this jack for private listening.

6. (POWER)

Press to turn the TV on and off.

7. POWER INDICATOR


Blinks and turns off when the power is on and lights up in stand-by mode.

8. SPEAKERS

9. REMOTE CONTROL SENSOR

Aim the remote control towards this spot on the TV.

10-2 Connection Panel



1. Connecting an Aerial or Cable Television Network

To view television channels correctly, a signal must be received by the set from one of the following sources:

- An outdoor aerial / A cable television network / A satellite network

2. Connecting Component Devices (DTV/DVD)

- Connect component video cables (optional) to component connector ("PR", "PB", "Y") on the rear of your set and the other ends to corresponding component video out connectors on the DTV or DVD.
- If you wish to connect both the Set-Top Box and DTV (or DVD), you should connect the Set-Top Box to the DTV (or DVD) and connect the DTV (or DVD) to component connector ("PR", "PB", "Y") on your set.
- The PR, PB and Y connectors on your component devices (DTV or DVD) are sometimes labeled Y, B-Y and R-Y or Y, Cb and Cr.
- Connect RCA audio cables (optional) to i°R - AUDIO - L_i± on the rear of your set and the other ends to corresponding audio out connectors on the DTV or DVD.

3. Connecting External A/V Devices

- Connect RCA (optional) or S-VIDEO cable (optional) to an appropriate external A/V device such as VCR, DVD or Camcorder.
- Connect RCA audio cables (optional) to i°R - AUDIO - L_i± on the rear of your set and the other ends to corresponding audio out connectors on the A/V device.

4. Connecting Set-Top Box, VCR or DVD

- Connect the VCR or DVD SCART cable (optional) to the SCART connector of the VCR or DVD.

5. Connecting DVI

- Connect the DVI connector to the DVD connector.
- Connect the stereo audio cable (optional) to "R - AUDIO - L" on the rear of your set and the other end to "Audio Out" of the sound card on your DVD.
- DVI dose not support PC function.

6. Connecting Computer

- Connect the D- Sub cable (optional) to "PC (PC IN)" on the rear of your set and the other end to the Video Card of your computer.
- Connect the stereo audio cable (optional) to "AUDIO (PC IN)" on the rear of your set and the other end to "Audio Out" of the sound card on your computer.

7. Kensington Lock

- The Kensington lock (optional) is a device used to physically fix the system when used in a public place.
- If you want to use a locking device, contact the dealer where you purchased the TV.

10-3 Remote Control




1. Television Standby button
2. Number buttons for direct channel access
3. One/Two-digit channel selection
4. ⊕ Volume increase
⊖ Volume decrease
5. Temporary sound switch-off
7. Displays the main on-screen menu
8. Sound effect selection
9. Sound mode selection
10. Press to automatically store selected TV/cable channels
11. Use to store and delete channels to/from memory
12. Picture freeze
13. Selects the TV mode directly
14. Previous channel
15. P ⊙ Next channel
P ⊙ Previous channel
16. Available source selection
17. Use to see information on the current broadcast
18. Exit the on-screen menu
19. Control the cursor in the menu
20. Picture size selection
21. Picture effect selection
22. Picture-In-Picture On/Off
23. Automatic Power-off
24. Selects the PC mode directly

- Teletext Functions -

3. Teletext hold
6. Teletext display/mix both teletext information and the normal broadcast
7. Teletext index
10. Teletext store
11. Teletext sub page
13. Exit from the teletext display
15. P ⊙ : Teletext next page
P ⊙ : Teletext previous page
16. Teletext mode selection (LIST/FLOF)
17. Teletext reveal
22. Teletext cancel
23. Teletext size selection
- 8,9,20,21. Fastext topic selection

10-4 Installing the Stand



1. Place the TV faced down on a soft cloth or cushion on a table.
2. Put the stand into the hole at the bottom of the TV.
3. Insert screw into the hole indicated and tighten

Memo