

Samsung TV
F/W Upgrade Guide
Model : 410 Series

PS42A410C1D



Samsung Electronics

Step1. How to prepare the USB Memory Drive

1. Save the firmware file from Samsung.com onto your computer.


File Name : T-PRPDAU.exe




2. Connect the USB Memory Drive to the USB port of your PC.
Copy the file onto the USB Memory Drive.

3. Go to the USB Memory Drive and then double click the file.


4. Press the “Unzip” button.



5. Unzipping is in progress.




6. After completing, please press the “OK” and “Close” button.



7. A folder containing the firmware files has been added to the USB memory drive.
Folder Name : T-PRPDAU

8. Safely disconnect the USB memory drive by right clicking the green check mark on the taskbar and then left click “Safely Remove”.

Step2. Firmware Update with the USB Memory Drive




1. Turn the TV on and then insert the USB Drive into WISELINK (USB) port on the side of the TV.



2. If WISELINK message appears on the screen, select "NO" and press "Enter" button on the remote control.



3. Press the "Menu" button on the remote control.
4. Go to "Setup" and "SW Upgrade", then press the "Enter" button.



5. Select "BY USB", then press the "Enter" button

Step2. Firmware Update with the USB Memory Drive




5. The TV will begin scanning the USB Memory Drive.



6. A message will appear asking if you want to perform the firmware update.

Select "OK" and then press the "Enter" button on the remote control.



7. The firmware update will start. This should take 3 min to 5 min.


!!! Do not disconnect the USB drive during this step
!!! Do not unplug the power cable or turn the TV off.




8. After completing the firmware update, the TV will turn off in 3 seconds and turn back on.

9. It is safe to remove the USB Memory Drive after the TV turns on.

Step3. How to check the Firmware Version



1. Press the Menu button on your remote control




2. Go to Setup. On the Setup Menu, select SW Upgrade.

A close-up of the bottom of the TV screen. It displays the following text: 'MODULE : T-AMBAUSC-1002.3, DATE : PANEL : 40A 1, MICOM : T-AMBAUSM-0014' and 'RFS : T-AMBAUSC-20080212, 2008-02-26'. A red circle highlights the '1002.3' in the first line, and a red arrow points from it to the text below.

MODULE : T-AMBAUSC-1002.3, DATE : PANEL : 40A 1, MICOM : T-AMBAUSM-0014
RFS : T-AMBAUSC-20080212, 2008-02-26

TV F/W Version (for example) : 1002.3



3. Press the Info button on your remote control. The firmware version appears at the bottom of the screen.

❖ Firmware Upgrade Error Messages

1. If the USB Memory Drive was not inserted into WISELINK port.



2. If the firmware was not loaded on the USB Memory Drive.



3. While update is in progress, please do not pull the USB Memory Drive out or do not unplug the power cable.

