



# PDP-TELEVISION

Chassis: F59A(P\_Asia)\_Carnelian  
Model : PS42A410C1DXXY  
PS50A410C1DXXY

# ***SERVICE*** *Manual*

## PDP-TELEVISION



PS42A410C1D  
PS50A410C1D

## CONTENTS

1. Precaution
2. Product Specification
3. Disassembly & Reassembly
4. Troubleshooting
5. Exploded View & Part List
6. Wiring Diagram

Refer to the service manual in the GSPN (see the rear cover) for the more information.



#### **GSPN (Global Service Partner Network)**

Area	Web Site
North America	service.samsungportal.com
Latin America	latin.samsungportal.com
CIS	cis.samsungportal.com
Europe	europe.samsungportal.com
China	china.samsungportal.com
Asia	asia.samsungportal.com
Mideast & Africa	mea.samsungportal.com

This Service Manual is a property of Samsung Electronics Co.,Ltd.  
Any unauthorized use of Manual can be punished under applicable  
International and/or domestic law.

© Samsung Electronics Co., Ltd. **May. 2008**  
Printed in Korea  
**AA82-05309A**

---

# Table of Contents

---

## Chapter 1 Precaution

■ 1-1 Safety Precautions .....	1-1
■ 1-2 Servicing Precautions .....	1-3
■ 1-3 Static Electricity Precautions .....	1-4
■ 1-4 Installation Precautions .....	1-5

## Chapter 2 Product Specification

■ 2-1 Product Specification .....	2-1
■ 2-2 Specifications Analysis .....	2-2
■ 2-3 Accessories .....	2-4

## Chapter 3 Disassembly & Reassembly

■ 3-1 Overall Disassembly & Reassembly .....	3-1
--	-----

## Chapter 4 Troubleshooting

■ 4-1 Troubleshooting .....	4-1
■ 4-2 Adjustment .....	4-20
■ 4-3 Upgrade .....	4-38

## Chapter 5 Exploded View & Part List

■ 5-1 PS42A410C1DXXY Exploded View .....	5-1
■ 5-2 PS50A410C1DXXY Exploded View .....	5-3
■ 5-3 PS42A410C1DXXY Service Item .....	5-5
■ 5-4 PS50A410C1DXXY Service Item .....	5-6

## Chapter 6 Wiring Diagram

■ 6-1 Overall Wiring .....	6-1
----------------------------	-----