



4. Disassembly and Reassembly

4-1. Removal of ASSY BODY CONTROL


- 1) Detach the BUTTONC/REEL & BUTTON SWITCH from main body by pushing the hinge with a flat head screw driver.




- 2) After loosening three screws, detach the ASSY BODY CONTROL from main body by lifting the hands.



- 3) Detach the GUARD CORD by hitting the locking hook with a small hammer.




- 4) Separate the PANEL DECO, PANEL CONTROL etc from the ASSY BODY CONTROL by pushing the locking hook with a flat head screw between BODY CONTROL and PANEL MID.





4-2. Removal of ASSY COVER DUST

- 1) First, separating the CONNECTOR HOUSING from the CONNECTOR HEADER of PBA MAIN. Second, open the ASSY COVER DUST. Third, detach the ASSY COVER DUST from the main body with pushing the hinge by the hand.




- 2) Separate WIRE H/LAMP, PBA LAMP, GRILLE BACK, CLAMPER DUST etc from ASSY COVER DUST by loosening six screws.






4-3. Removal of ASSY BODY MID


- 1) Separate the CONNECTOR HOUSING from the CONNECTOR HEADER of PBA MAIN and loosen the one screw and detach PBA DISPLAY.




- 2) Detach ASSY BODY MID from by main body loosening six screws.



- 3) Separate BODY DUST, BAND BODY, BODY MID from ASSY BODY MID by loosening four screws.




- 4) Separate SWITCH PRESSURE from BODY DUST and Detach the ASSY DAMPER from BODY DUST by loosening one screw.




4-4. Removal of PBA MAIN

- 1) Separate the CONNECTOR HOUSING from the CONNECTOR HEADER of PBA MAIN and loosen the one screw and detach the PBA MAIN.




4-5. Removal of ASSY MOTOR


- 1) Loosen one screw from the ASSY BODY BASE and detach the ASSY MOTOR.



- 2) Separate the ASSY MOTOR by loosening two screws.




- 3) Separate CUSHION-MOTOR F, CUSHION RING, HARNESS MOTOR, SPONGE, CUSHION RING B, MOTOR from the ASSY MOTOR by loosening four screws.



4-6. Removal of ASSY CORD REEL

- 1) Lifting up the ASSY CORD REEL with be careful the COVER C/REEL's automatic rotating by SPRING SPIRAL and lifting the ASSY LEVER BRAKE.



4-7. Assembly of ASSY CORD REEL

- 1) Hold the BODY REEL and wind the POWERCORD about 3~4 turns.
- 2) When the winding is completed, immediately assemble the CORD REEL to the body.

