



SL-12D EXPLODED DRAWING

NO.	PART NUMBER	DESCRIPTION	QTY
107	660-MPH30050-21-00	MACHINE SCREW 3X5	0
106	650-000SL827-01-00	WIRE CLAMP	1
105	650-000SL827-00-00	WIRE CLAMP	1
104	650-0SM8826-00-00	MOUNTING BRACKET	1
103	662-HNM6040-00-00	M5 HEXAGON NUT	1
102	661-SIM60000-00-00	SPRING WASHER M5	1
101	660-MHX50140-03-00	HM 5X14 CHROMATE	1
100	650-000SL806-01-00	HEAT SINK	1
99	650-000SL805-00-00	TOP COVER	1
98	432-000M278-01-00	DM DNO MECHANISM	1
97	660-EPH26048-27-00	SCREW 2.6X4	2
96	660-EPH26048-27-00	SCREW 2.6X4	4
95	650-000SL815-00-00	DECK BRACKET	1
94	660-MPH30050-21-00	SCREW 3X5	3
93	650-000SL833-00-00	IC BRACKET	1
92	660-TPH30081-23-00	TapPin 3X8	1
91	661-ERM1500-04-00	E-RING	1
90	600-000SL1005-00-00	BEVEL WHEEL	1
89	600-000SL1001-00-00	GEAR "A"	1
88	660-MBH20030-23-00	SCREW 2.0X3	2
87	410-0000SL10-01-00	DOWN BOARD	1
86	600-000SL1004-00-00	WORM	1
85	340-000M50Y-00-00	DC MOTOR	1
84	443-94007520-00-00	Rubber Contact	1
83	650-000SL801-00-00	MAIN CHASSIS	1
82	650-000SL1001-00-00	MOTOR BRACKET	1
81	650-000SL1003-00-00	PIN "A"	1
80	650-000SL1003-00-00	BACK-E	1
79	650-000SL1004-00-00	PIN "B"	1
78	600-000SL1002-00-00	GEAR "B"	1
77	650-000SL1005-00-00	BRASS BUSHING	1
76	650-000SL1002-00-00	SPRING	1
75	650-000SL828-00-00	DECK BRACKET	2
74	660-MPH26040-23-00	SCREW 2.6X4	5
73	650-000SL823-00-00	PCR BRACKET	1
72	410-0000SL10-01-00	SN BOARD	1
71	600-000SL828-00-00	LOCKER "B"	1
70	660-MPH26040-23-00	SCREW 2.6X4	3
69	660-MPH26040-24-00	SCREW 2.6X5	2
68	660-MPH30060-24-00	SCREW 3X6	2
67	600-000SL825-00-00	DISC INDICATOR	1
66	600-000SL826-00-00	CD EJECT BUTTON	1
65	410-0000SL8-01-00	OPEN BUTTON SPRING	1
64	660-TBH17053-23-00	SCREW 1.7X5	2
63	701-0000SL801-00-00	FIBER SHEET	1
62	410-000SL802-02-00	MAIN BOARD	1
61	650-000SL810-00-00	LOCKER "A"	1
60	650-000SL826-00-00	SPRING "B"	1
59	650-000SL823-00-00	PIN "D"	3
58	650-000SL811-00-00	LOCKER "B"	1
57	410-000000-01-00	DMO SERVO BOARD	1
56	660-MBH20040-23-00	SCREW 2.0X4	2
55	410-0000SL8-04-00	RESET BOARD	1
54	650-000SL822-00-00	PIN "C"	2
53	650-000SL814-00-00	DECK BRACKET	1

NO.	PART NUMBER	DESCRIPTION	QTY
52	660-EPH26048-27-00	SCREW 2.6X4	2
51	650-000SL802-00-00	FRONT BRACKET	1
50	660-EPH30063-21-00	SCREW 3X5	2
49	661-ERM6000-04-00	E-RING	7
48	650-000SL809-00-00	ARM	2
47	650-00000011-00-00	DISC FELT	1
46	703-00000001-00-00	DISC PROOF FELT	1
45	660-MPH26050-24-00	SCREW 2.6X5	2
44	600-000SL802-00-00	CD BASE	1
43	600-000SL823-00-00	CONNECTOR COVER	1
42	410-00000008-10-01	FLEXIBLE PCB	1
41	374-00000000-00-00	DETACHABLE CONNECTOR	1
40	650-000SL825-00-00	SPRING "A"	1
39	650-000SL821-00-00	PIN "B"	1
38	600-000SL827-00-00	LOCKER "A"	1
37	650-000SL804-00-00	LOADING BRACKET	1
36	650-000SL805-00-00	SLIDE BRACKET	1
35	650-000SL123-00-00	SCREW	4
34	600-000SL1203-00-00	TRIM PLATE	1
33	600-TBH20083-24-00	"B" TYPE 2X8	3
32	600-TBH20081-24-00	"A" TYPE 2X8	1
31	600-000SL1204-00-00	HANDY BACK	1
30	660-TPH17043-24-00	SCREW 1.7X4	4
29	410-SL1204-01-03	PANEL BOARD	1
28	600-000SL1206-00-00	REFLECTOR "B"	1
27	600-000SL1205-00-00	REFLECTOR "A"	1
26	439-000M63-00-00	VFD DISPLAY	1
25	650-000SL1203-00-00	VFD HOUSE	1
24	650-000SL1201-00-00	WHITE SPONGE	2
23	600-000SL1221-00-00	FUNCTION BUTTON "B"	1
22	600-000SL1235-00-00	RELEASE BUTTON "E"	1
21	600-000SL1219-00-00	BUTTON BRD	1
20	600-000SL1218-00-00	BUTTON "B"	1
19	600-000SL1217-00-00	BUTTON "S"	1
18	600-000SL1216-00-00	BUTTON "A"	1
17	600-000SL1215-00-00	BUTTON "J"	1
16	600-000SL1214-00-00	BUTTON "Z"	1
15	600-000SL1213-00-00	BUTTON "T"	1
14	600-000SL1212-00-00	BUTTON "MS"	1
13	650-00000000-01-00	OPEN BUTTON SPRING	1
12	600-000SL1229-00-00	OPEN BUTTON	1
11	600-000SL1220-00-00	FUNCTION BUTTON "A"	1
10	600-000SL1231-00-00	FUNCTION BUTTON "C"	2
9	600-000SL1211-00-00	MODE/SEL BUTTON	2
8	600-000SL1233-00-00	VOL/TUNER ADAPTOR	2
7	600-000SL1232-00-00	VOL/TUNER BTTON	2
6	600-000SL1201-00-00	HANDY FRONT	1
5	600-000SL1208-00-00	POWER REFLECTOR	1
4	600-000SL1223-00-00	BUTTON COVER "A"	1
3	600-000SL1222-00-00	BUTTON COVER "T"	1
2	600-000SL1230-00-00	POWER BUTTON	1
1	600-000SL1204-00-00	DISPLAY LENS	1