

Applicable Country & Regions:

All Regions

Product Service Manual – Level 3

Service Manual for BenQ:

Projector/MP515 (Black)

<9H.J0A77.000>

Projector/MP515st(White)

<9H.J1P77.000>



Version: 00a

Date:2009/06/09

Notice:


For RO to input specific “Legal Requirement” in specific NS regarding to responsibility and liability statements.

Please check BenQ's eSupport web site, <http://esupport.benq.com>, to ensure that you have the most recent version of this manual.


First Edition (Jun 2009)

© Copyright BenQ Corporation 2009. All Right Reserved.

Schematics—Main board:




D-sub RGB Input 1




USB Input


These parts of this portion should be connected closely.




S-Video Input




H1, V1 Buffer




Video Input







HDMI INTERFACE




Audio Processor




Audio P5V Power




Audio Power Amplifier










Speaker L




Speaker R


















OPEN
















Debug Port JTAG




















Power board:





Power board:

