


14"21" COLOR TV BASIC SCHEMATIC DIAGRAM

Model KLS512 Ver. A02



SAFETY NOTE
 1. DISCONNECT FROM AC POWER SOURCE.
 2. DISCONNECT FROM AC POWER SOURCE.
 3. DISCONNECT FROM AC POWER SOURCE.
 4. DISCONNECT FROM AC POWER SOURCE.
 5. DISCONNECT FROM AC POWER SOURCE.
 6. DISCONNECT FROM AC POWER SOURCE.
 7. DISCONNECT FROM AC POWER SOURCE.
 8. DISCONNECT FROM AC POWER SOURCE.
 9. DISCONNECT FROM AC POWER SOURCE.
 10. DISCONNECT FROM AC POWER SOURCE.