



PLASMA DISPLAY TV

Chassis: F65A(P_HD)_B430

Model : PS42B430P2WXXH

SERVICE Manual

PLASMA DISPLAY TV



PS42B430P2W

CONTENTS

1. Precaution
2. Product Specification
3. Disassembly & Reassembly
4. Troubleshooting
5. Exploded View & Part List
6. Wiring Diagram

Refer to the service manual in the GSPN (see the rear cover) for the more information.



GSPN (Global Service Partner Network)

Area	Web Site
North America	service.samsungportal.com
Latin America	latin.samsungportal.com
CIS	cis.samsungportal.com
Europe	europe.samsungportal.com
China	china.samsungportal.com
Asia	asia.samsungportal.com
Mideast & Africa	mea.samsungportal.com

This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under applicable
International and/or domestic law.

© Samsung Electronics Co., Ltd. **Apr. 2009**
Printed in Korea
AA82-05791A

Table of Contents

Chapter 1 Precaution

■ 1-1 Safety Precautions	1-1
■ 1-2 Servicing Precautions	1-3
■ 1-3 Static Electricity Precautions	1-4
■ 1-4 Installation Precautions	1-5

Chapter 2 Product Specification

■ 2-1 Product Specification	2-1
■ 2-2 Specifications Analysis	2-3
■ 2-3 Accessories	2-4

Chapter 3 Disassembly & Reassembly

■ 3-1 Overall Disassembly & Reassembly	3-1
--	-----

Chapter 4 Troubleshooting

■ 4-1 Troubleshooting	4-1
■ 4-2 Adjustment	4-14
■ 4-3 Upgrade	4-32

Chapter 5 Exploded View & Part List

■ 5-1 PS42B430P2WXXH Exploded View	5-1
■ 5-2 PS42B430P2WXXH Service Item	5-5

Chapter 6 Wiring Diagram

■ 6-1 Overall Wiring	6-1
----------------------------	-----