



Installing the monitor driver

When you install the Monitor Driver, resolution and frequency are automatically set to the Monitor. So you can work on the clearer display. Monitor Driver CD (or diskette) will be provided for the 17-inch or higher Model (higher than 70kHz) with LCD. If your monitor is not the one above or you lost the CD (or diskette) , you can download the driver on <http://www.lge.com>

■ Windows 95 / 98 / ME users


1. Click on **Start**, select **Settings**, then click **Control Panel**.
2. Double click on **Display**.
3. Click on the **Settings** tab.
4. Click on **Advanced...** and select the **Monitor** tab.
5. Click on **Change...** to select the model of the LG Monitor you are using.
6. Click on **Have Disk...**
7. Click on **Browse...** to find the *.INF file on your CD-ROM (or diskette) (under the **Drivers (Windows...)** directory) and click on **OK**.
8. Select your monitor type from the **Models** box and click on **OK** to install the selected monitor.

■ Windows 2000 users

1. Click on **Start**, select **Settings**, then click **Control Panel**.
2. Double click on **Display**.
3. Click on the **Settings** tab.
4. Click on **Advanced...** and select the **Monitor** tab.
5. Click on **Properties**.
6. Click on **Driver** tab.
7. Click on **Update Driver...** and click on **Next**.
8. Select the **Recommended** option and click on **Next**.
9. Check the **Specify a Location** box.
10. Find and open the *.INF file on your CD-ROM (or diskette) (under the **Driver (Windows...)** directory) and click on **OK**.
11. Click on **Next** to install the selected monitor.


Important Notice

This message may appear several times during the installation of your monitor driver. Click **Yes** to continue (Windows 2000). This action will not harm your monitor or system.



■ Windows XP users

1. Click on **Start**, select **Settings**, then click **Control Panel**.
Double click on **Display**.



2. Select the **Settings** tab and Click on **Advanced....**




3. Select the **Monitor** tab and Click on **Properties**.




4. Click on **Driver** tab and Click on **Update Driver...**



5. Select the **Install from a list or specific location (Advanced)** option and click on **Next**.



6-1. Select the Search for the best driver in these locations and Click on Next.



If you see 'Cannot Continue the Hardware Update Wizard' window on your monitor, Click on **Back** and then follow these steps (5 → 6-2 → 7).



6-2. Select the Don't Search. I will choose the driver to install and Click on Next.



Select the **Have Disk.....** and click on **Browse**.



Find and open the *.INF file on your CD-ROM (or diskette) (under the \Driver (\Windows...) directory) and click on **OK**.

Click on **Next** to install the selected monitor.




7. Click on **Finish**.



Important Notice

This message may appear several times during the installation of your monitor driver. Click **Continue Anyway** to continue (Windows XP). This action will not harm your monitor or system.



USB Install Guide

The following guide is only for the USB-Monitor software supported Monitor.

■ INSTALL

1. Before setting up the USB program, Connect the monitor to PC with the USB signal cable.
2. Insert the monitor installation disk (or CD) into the floppy disk drive (or CD-ROM drive).
3. Select the **MNT_USB** folder, and double click the **Setup**.
4. **USB Monitor** window is displayed, click the **Next**, and repeat that.
5. Click the **Finish** button and setup is completed.
6. Select the **Display Properties**, and then you use the **USB Monitor** function.

■ UNINSTALL

1. Select the **Settings** and **Control Panel**, Double click the **Add/Remove Programs**.
2. Select the **USB Monitor**.
3. Click the **Add/Remove** button and the Program is removed.

*Caution: This Program is supported **WINDOWS98** and Higher.*